

Tilt switch module Experiment


Introduction of Tilt switch module

Tilting switch module is also known as the beaded switch, the steel ball switch, is actually a vibration switch. It has a different name, but it works the same way. The ball ball controls the connection or disconnection of the circuit by contacting or not contacting the metal plate. Simply put, like turning a light on or off, the light will go on if the switch touches the inner metal plate, and off when the switch leaves. Contact with a metal terminal or changing the path of light with beads in a switch will produce a conductive effect.


Tilting switches are widely used, such as: tire pressure monitoring system (TPMS), pedal lamp, digital photo frame rotation, flip camera, anti-theft system, etc. The common spherical switches on the market are sw-200d, sw-300da, sw-520d and so on. Is OFF in the static state. When it is subjected to an external touch force to achieve the appropriate vibration, or moving at the appropriate speed to generate the appropriate centrifugal force, the needle will instantly be in the ON state, changing the electrical characteristics. When the external force disappears, the electrical characteristics return to the closed state.

The tilt sensor module adopts the original tilt switch sw-460d of MEC, which has high sensitivity and is generally used to detect the change of object Angle. When the module has no tilt or the tilt Angle cannot reach the set threshold, the DO port outputs the high level. When the sensor's tilt Angle exceeds the set threshold, the module D0 outputs the low level. Digital output D0 can be directly connected with the single-chip microcomputer, through the single-chip microcomputer to detect high and low level, thus to detect the change in the object Angle; Can be applied to tire pressure monitoring system (TPMS), bicycle lamp, digital photo frame rotation, screen rotation, video lens flip, anti-theft system





tilt switch module figure



Internal principle of tilt switch

The experiment purpose

- 1 Understand the working principle of tilt switch module
- 2 The tilting switch module controlled by Arduino is used to realize the function of anti-theft alarm.

The component list

- 1 Keywish Arduino UNO R3 motherboard
- 2 Breadboard



- 3 USB cable
- 4 Tilt switch module * 1
- 5 LED module* 1
- 6 Active buzzer *1
- 7 jumper wires

The experimental principle

Using the working characteristics of the tilt switch module, when the circuit board is in the static state, the tilt switch module is in the state of disconnection. When an external force touches the circuit board, which causes the ball and wire in the tilt switch to close, the alarm will be triggered, the LED will be on, and the buzzer will sound. When back to rest, the LED goes off and the buzzer stops ringing..


Wiring the circuit

Arduino UNO	Active buzzer
13	+
GND	-

Arduino UNO	LED
12	+
GND	_

Arduino UNO	Vibration switch module
nkai12	DO
5V	VCC(+)
GND	GND(-)





Arduino ID Code

```
int Led=11;
                                                                                            int
int Buzzer pin=13;
                                                                                            int .
int buttonpin=12;
                                                                                            int
int val=0;
                                                                                            void
void setup()
{
 pinMode(Led,OUTPUT);
 pinMode(Buzzer_pin,OUTPUT);
 pinMode(buttonpin,INPUT);
                                                                                            }
                                                                                            void
}
void loop()
 val=digitalRead(buttonpin);
 if(val==0)
     digitalWrite(Led,HIGH);
     digitalWrite(Buzzer_pin,HIGH);
     delay(3000);
```

pir

pir

Sei

Va

Sei

if


els



```
else
{
    digitalWrite(Led,LOW);
    digitalWrite(Buzzer_pin,LOW);
}
```


After burning the program, touch the tilting switch module slightly, and the alarm will be triggered. The LED light will be on, and the buzzer will sound.

Experiment Result



If you have a Sensor V5.0 expansion board in your kit, you can use the following wiring for more convenience.





Mlock graphical programming program

The main blocks used in mBlock programming are:



```
--Set variable read values

Read Digital Pin 12
--Read the value of the numeric pin

Serial Print Number val

--Serial print variables

set digital pin 13 output as HIGHT
--Sets the state of the digital pin output
```

MBlock writes the tilting switch program as shown in the figure below:

```
sensor Program

Set Baud Rate 9600*

forever

set val vo Read Digital Pin 12

Serial Print Number val

if val = 0 then

set digital pin 11 output as HIGH*

set digital pin 13 output as HIGH*


else

set digital pin 11 output as LOW*

set digital pin 13 output as LOW*
```

You can also use mBlcock to directly open the written program file, which is a.sb2 file. Here are the steps to open it:







文件名(<u>N</u>):

Scratch 2 Project (*.sb2)

打开(O)










Mixly graphical programming program





MagicBlock graphical programming program

